

Jan Skopový (hw.ddfu.org)

hello@ddfu.org

+420 731 533677

12.04.25 12:31:21

HTC VIVE BUSINESS+ PRO 1 ROK



Cena celkem:	3 997 Kč (bez DPH: 3 303 Kč)
Kód zboží:	VRHTC0042
Part No.:	69HVABMSB12M01-00
Záruka:	12 měs. IČO / 24 měs. EU
Stav:	Nové zboží

Popis

HTC Business+ Pro

HTC VIVE Business+ je řešení softwaru a služeb pro správu **HTC VIVE Focus 3**. Přizpůsobte si samostatné náhlavní soupravy VR tak, aby vyhovovaly vašim firemním potřebám. Licence je pro 1 uživatele a je platná 1 rok. Verze Pro nabízí **1 GB cloudového úložiště** pro sdílení map.

Licence je určena **pro komerční použití**. VIVE Business+ nepodporuje licencovaný obsah z VIVE Business AppStore nebo VIVEPORT.

Správa zařízení

Rychle a snadno zaregistrujte náhlavní soupravy pomocí naskenování QR kódu, aktualizujte nastavení/konfigurace hardwaru a spravujte svá zařízení na dálku.

Správa obsahu

Nahrávejte vlastní obsah, spravujte knihovnu a instalujte aplikace do všech náhlavních souprav VIVE Focus 3 odkudkoli.

Vzdálená správa obsahu

Přístup k obsahu a jeho správa v rámci organizace není nikdy jednoduchá. VIVE Business+ umožňuje vzdáleně nahrávat a spravovat všechny aplikace a verze v cloudu. Centrálně spravujte a spolehlivě škálujte svá nasazení.

Správa uživatelů

Přidejte uživatele a nastavte oprávnění pro role správce, editora či diváka. Vytvořte více organizací pro samostatné týmy. Udržujte kontrolu nad všemi na jednom místě.

Správa skupin

Vytvořte skupinu pro svá zařízení a rychle a efektivně nasazujte aktualizace nebo aplikujte přizpůsobitelná nastavení. Změňte skupinová nastavení ROM, aplikací, map a zobrazte okamžité aktualizace ve všech seskupených zařízeních.

Pokročilé funkce

Poskytněte uživatelům lepší zážitky díky přizpůsobitelným možnostem uživatelského rozhraní a režimům sledování VIVE Location-Based Software Suite (LBSS).

Vzdálené monitorování a ovládání zařízení

Sledujte stav baterie náhlavní soupravy a ovladače, stav Wi-Fi a další důležité údaje. Mějte lepší kontrolu nad svými zařízeními odkudkoli. Vzdáleně restartujte, vypínejte a resetujte náhlavní soupravy do továrního nastavení.

Funkce a vlastnosti:

VIVE BUSINESS+ FEATURES						
	FEATURES	DESCRIPTION	STANDARD	PRO	ULTIMATE	NOTES
User Admin	Overview Dashboard	Organization enrolled device lists, available seats, expiration... etc.	•	•	•	
	Role-based User Management	Admin, Editors, Viewer roles	•	•	•	
	Member Management	Add, delete, and assign user accounts to organizations	•	•	•	
	Permission Management	Admin privileges for modifying user permissions	•	•	•	
	Cloud Storage	Storage for configurations, maps, and custom content files for remote installation		1GB	5GB	per device
	Code Redemption	Organization creation and seats redemption	•	•	•	
Device Management	NEW QR Code Enrollment	QR-Code initiated device setup and enrollment for the VIVE Focus 3	•	•	•	
	NEW Standard Device Status	Device battery level, sync time... etc. dashboard	•	•	•	
	NEW Batch Configuration	Batch configuration for device groups	•	•	•	
	NEW Device Groups	Device grouping and group management features	•	•	•	
	NEW Issue Report/Tracking	Device logging on VBMS and issue ticketing	•	•	•	
	NEW Remote Device Management	Remote device reboot, shutdown, and wipe... etc.	•	•	•	
	NEW Advanced Device Status	Device storage, content list... etc.	•	•	•	
	NEW Remote Content Management & Distribution	Remote content installation and distribution to device groups over network (APK and OBB files)			•	
	Customized Boot Screen	Custom device boot up animation			•	
System Updates	Offline Device ROM Update	Update to ROM manually using SD card	•	•	•	
	NEW Device management and FOTA Assignment	System version management, supporting device groups and support force updates.	•	•	•	
	NEW ROM Update via SD Card	Automatically update to specific ROM version directly by SD card	•	•	•	
Advanced Tracking Features (LBSS)	Visual Odometry (VO) Tracking Mode	Access to VO Mode	NEW •	•	•	
	Immersive Customization	Disable default system UI elements (refer to batch configuration)		•	•	
	LBE Configurations	Tracking mode selection and corresponding settings (refer to batch configuration)		•	•	
	Map Sharing	Map sharing between HMDs for alignment		•	•	
	Advanced Tracking Features	MBLS, MBSA, Drift Prevention Mode		•	•	

BATCH CONFIGURATION SETTINGS								
	FEATURES	STANDARD	PRO	ULTIMATE		STANDARD	PRO	ULTIMATE
General	System language	•	•	•			•	•
	Timezone	•	•	•			•	•
	Network Time enabling	•	•	•			•	•
	Double click to show pass through	•	•	•			•	•
	Allow BT	•	•	•			•	•
	Hand tracking enable/disable	•	•	•			•	•
	Show/hide Vive Sync	•	•	•			•	•
Wi-Fi settings	Wi-Fi certificate	•	•	•			•	•
	Wi-Fi setup	•	•	•			•	•
	VPN certificate	•	•	•			•	•
	VPN setup	•	•	•			•	•
Device settings	Boundary color	•	•	•			•	•
	Boundary transparent	•	•	•			•	•
	Show pass through automatically when out of boundary	•	•	•			•	•
	Always show floor bound	•	•	•			•	•
	Power frequency	•	•	•			•	•
	Allow recording and casting	•	•	•			•	•
	USB debugging	•	•	•			•	•
Kiosk mode	Period to enter sleep mode	•	•	•			•	•
	Hide pre-loaded content -> VIVE Sync	•	•	•			•	•
	Hide pre-loaded content -> Firefox Reality	•	•	•			•	•
	Hide pre-loaded content -> VIVE Business Streaming	•	•	•			•	•
	Kiosk mod - select content	•	•	•			•	•
	Kiosk mod - password	•	•	•			•	•
	Kiosk mod - Activate kiosk mode	•	•	•			•	•
	Kiosk mod - network mode (any, pre-set, offline)	•	•	•			•	•
	Kiosk mod - interaction mode	•	•	•			•	•
	Kiosk mod - Show/hide tutorial/opening video/wearing guide	•	•	•			•	•
UI Related	Kiosk mod - Allow BT connection	•	•	•			•	•
	Kiosk mod - Allow casting	•	•	•			•	•
	Kiosk mod - Allow screenshot and recording	•	•	•			•	•
	Kiosk mod - Allow USB translation	•	•	•			•	•
	Disable controller pairing and the UI after initial setup						•	•
	Disable Vive menu on the R controller and HMD button						•	•
	Disable Function Menu						•	•
	Disable USB connection dialog						•	•
	Disable Volume adjustment Bar						•	•
	to consent volume warning dialog by volume up key						•	•
Customization	Disable Volume safety notification						•	•
	Disable low battery notification						•	•
	Disable IPD adjustment overlay						•	•
	Skip OOB						•	•
	Customized boot logo						•	•
	Customized boot animation						•	•
	Customized boot duration (logo & animation)						•	•
	To Hide tabs from MainNav						•	•
	enable System firmware update management						•	•
	Disable content transition						•	•
Tracking Features	Disable shutdown screen image						•	•
	enable Lost tracking event integration						•	•
	Disable lost tracking animation						•	•
	Disable lost tracking black background						•	•
	Marker-based location sharing (VO mode only)						•	•
	enable Marker-based drift prevention						•	•
	Disable Reset View function						•	•
	Support 1 controller 1 wrist tracker						•	•
	Enable hand tracking as default						•	•
	Disable VIVE button on right controller						•	•
HW Keys	Disable volume up/down buttons on HMD						•	•
	Disable Headset button on HMD						•	•
	Disable hand gesture "palm pinch"						•	•
	Pop up Vive menu by single click headset button						•	•
	enable 2 ways communication on wrist tracker						•	•

BUSINESS BUILDING BLOCKS

BUSINESS WARRANTY AND SERVICES

Business Warranty & Support 2 or 3 years

Enterprise-grade support and services to protect your investment.

Two (or 3-years) warranty, phone support and expedited repair



VIVE Advanced Device Management System –services

Standard Tier Included with BWS

New VIVE Advanced Device Management System features

- QR Code enrolment
- NEW Device Status
- NEW Group Management
- XR Elite 3rd Party MDM use



Pro Tier Optional (F3 only)

- Remote Device Management
- Advanced device status
- Focus 3 Location Based Software Suite



Ultimate Tier Coming Later (F3 only)

- Content management and delivery with more content storage
- Advanced features like deep API integration

